SYSTEM DESCRIPTION

The seat belt tension reducer is adopted to the front seat belts. This mechanism can help reduce the belt tension applied to the occupants in the front seats when the seat belts are fastened.

PROBLEM SYMPTOMS TABLE

Seat Belt Tension Reducer

Symptom	Suspected Area	See page
Driver side tension reducer does not operate	1. ECU IG No. 1 fuse	-
	2. Front seat inner belt assembly (Driver side)	SB-24
	3. Front seat outer belt assembly (Driver side)	SB-29
	4. Wire harness	-
Front passenger side tension reducer does not operate	1. ECU IG No. 1 fuse	-
	2. Front seat inner belt assembly (Front passenger side)	SB-23
	3. Front seat outer belt assembly (Front passenger side)	SB-29
	4. Wire harness	-